

# Non-Destructive Industrial 3D CT Scanner





With the x-ray scanning technology used in RF's medical and dental CT scanner, which have seized the No.1 share in Japan,

we have applied and developed it into the industrial **3D scanner** at most affordable price.


### Dreams of every engineers have come true.

It enables to examine the object inside out in a 3D view without destroying it.

For the precious things you used to break for your inspection,

## they do not need to be broken, disassembled or torn apart.

From various angles, everything is transparent.., all things not seen from outside.



Reference: Head CT Tomography



No special qualification is reguired for this product.

With the RF's unique technology of the share No.1 medical CT scanner

Non-Destructive Industrial 3D CT Scanner

Manufacturer's direct, "one" price!

The size of microwave





# **Bottle (Resin)** [MPR -Multiplaner Reconstruction Rendering-] It displays the preferable slices of the 3D image reconstructed by the x-ray scan. The 3-way slices enable you to grasp the details of the object.


3D slices from any directions. All revealed from 360° angle.


You can adjust rotation and tilt at any angles and display the intermal cross section in real time (Color adjustment is [VR -Volume Rendering-] allabefor your preference.



0








Single mouse operation allows you Contrast in the image of colors to number is smaller alignmum (for 13 We are developing a soft ware to in information from the 3D scan image information from the 3D scan image.

of materials. X-ray penetration rate is higher when the atomic ropper (No.29), silver (No.47), metal (No.79), lead (No.82), etc. sons and draw the diagram automatically, based on the




### Non-Destructive Industrial 3D CT Scanner



### NAOMi-CT Specifications

Power source	Power source	AC 100-240V 50/60Hz	
	Consumption power	1.0 kVA ( Peak power during irradiation)	
X-ray source	Tube voltage	50-100kV	
	Tube current	2-10mA	
	Max power output	500W	
	High voltage generator	DC rectifier (Earlier ignition system)	
	Cooling	Oil and air	
	Focal spot size	0.5 mm	
Detector (FPD)	Active imaging area	123 mm×121 mm	
	Pixel size	100 μm	
	Pixels	1232×1216pixel	
	Grayscales	12bit	
Image aquisition	Image acquisition size	Partial scan - W:Ф56mm H:37-41mm Pixel size:0.068mm Normal scan - W:Ф83mm H:72-82mm Pixel size:0.136mm Offset scan - W:Ф151mm H:63-82mm Pixel size:0.205mm * Max object size - Ф250 x H:230mm * Contact us for customization for bigger objects	
	Resolution*	5 lp/mm 0.1mm	
	Object examples	Resin molded products, plastics, rubber products, food, cosmetics, stationery, toys, biological and bones, aluminum (approx. $\varphi$ 50~60mm max).	
Size	External dimensions	W623 mm×D338.5 mm×H297.5 mm * When opening the door W668mm	












Notification of x - ray equipment installation It is required to report when and where you install an x-ray equipment to the local Labor Standards inspection Office.\*

Equipment	Interlock	
X - ray leak dose rate	Under 1 $\mu$ Sv/h (No controlled area on the outside of the device)	
X = ray work chief qualification	Unnecessary	

\* In case of Japan.


Available size (Turntable) ø250mm Top view Front view 668 mm (When opening the door)



Partial scan - W:Φ56mm H:37-41mm Normal scan - W:Φ83mm H:72-82mm Offset scan - W: Ф151mm H: 63-82mm







TEL:1-800-383-3005 / FAX:1-800-799-9895 [URL] www.rfsystemlab.com/en [Email] os@rfsystemlab.com

Description of Business
Medical Field: Medical CT Scanner, Direct Digital Radiography Imaging Sensors, Medical Video Scopes
Dental Field: Dental CT Scanner, Digital Radiography Sensor, Intraoral Cameras
Industrial Field: NDT 30 CT Scanner, Digital Radiography NDT Systems, Industrial Video Borescopes
Development of Capsule Endoscope and Disposable Video Endoscopes

THE NEXT GENERATION CAPSULE ENDOSCOPE



The first battery-free endoscopic capsule. 9mm in diameter, 23mm in length. Swallowed like a pill.

Osi\_180306\_R\_MLct\_clg